

EilerCal™

Waterless calibration of
process weighing systems



www.EilerCal.com



+45 49 180 100



calibration@eilersen.com



Why use EilerCal™

The many advantages of EilerCal are due to the new and innovative approach to weighing system calibration. As EilerCal is an alternative to the use of liquids, tank cleaning is not needed before and after calibration, and thus calibration processes can be completed significantly faster, more accurately at the full range, and with a much lower environmental impact.

The EilerCal™ is compatible with multiple use cases

- ✓ Tanks standing on legs
- ✓ Tanks mounted on lugs
- ✓ Mobile totes and mixers

+ more



**ZERO
WATER
WASTE**

No need to waste expensive liquids or single use bags



**INCREASE
PRODUCTION
UPTIME**

Calibrate faster and reduce production downtime



**ELIMINATE
CONTAMINATION
RISKS**

No risk of contamination, no need for cleaning



**EASILY HIT
CALIBRATION
POINTS**

Easy to use for full scale calibration of all vessels

What is EilerCal™?

The EilerCal™ calibration concept removes the need for using liquids when calibrating process weighing systems. The use of EilerCal™ is easy, enabling frequent and quick calibration whenever it fits into the production schedule.

How to calibrate in 30 mins?

- 1 Attach the EilerCal cylinders
- 2 Use the pump to increase the load
- 3 Compare the load displayed on the EilerCal indicator with the installed weighing system
- 4 Adjust the weighing system if needed and repeat calibration
- 5 Detach the EilerCal cylinders





Eilersen
Calibration Solutions

Contact us today



www.EilerCal.com



+45 49 180 100



calibration@eilersen.com